

What respiratory protective devices require fit testing?

All tight fitting masks (negative and positive pressure) must be fit tested to the wearer. Positive pressure masks are fit tested under negative pressure.

Loose fitting headtops connected to a PAPR blower do not require fit testing.

AS/NZS 1715 and ISO 16975-3 recommend fit testing is to be conducted annually.

Fit testing required

Example of, but not limited to, styles and combinations that require fit testing



NOTE: Full face masks must be quantitatively fit tested

Fit testing NOT required

Examples of, but not limited to, loose fitting headtops and blower combinations that DO NOT require fit testing

