

Oasis Compac™ Neutral Disinfectant

Liquid disinfectant concentrate for disinfection of respiratory masks.



Oasis Compac™ is a disinfection and cleaning fluid Neutral pH, dual-chain quaternary ammonium-based one-step disinfectant, detergent, deodorant with broad spectrum bactericidal efficacy. 10 minute contact times for broad spectrum of microorganisms.

- Easy dosing with additional dosing unit
- High efficiency thanks to low usage concentrations in immersion baths

Registration

- AUST L 82244 HOSPITAL GRADE DISINFECTANT

Advantages

- Blend of two quaternary Ammonium compounds
- Effective against bacteria, fungi, viruses, mould, mildew and prevents cross contamination
- Neutral PH
- Deodorizer

APPLICATION INSTRUCTIONS

- Use disinfectant with caution. Always read the label and product information before use.
- Strictly observe the respective Dräger instructions for use for respiratory masks, respiratory protection equipment, and the application instructions of the disinfectant manufacturer!



Oasis Compac™ Neutral disinfectant
10 litre canister

DOSAGE

	Concentration (ml/L)	Exposure time (min.)
Disinfection of respiratory protection devices and respiratory protection equipment in immersion baths	12.5	10

ACCESSORIES

Dosing unit	Adjustable pump allows controlled dosing unit for exact preparation of aqueous disinfectant solutions	3504008
-------------	---	---------

DOSING TABLE – LIQUID

Litre(s)	Concentration for use 1.25 %
1 litre	12.5 ml
2 litres	25 ml
3 litres	37.5 ml
4 litres	50 ml
5 litres	62.5 ml
8 litres	100 ml
10 litres	125 ml
20 litres	250 ml
30 litres	375 ml

Application instructions:

Example: 8 litres = 1.25 % application solution = 100 ml disinfectant + 7.9 litres water.

Add concentrated disinfectant according to the water volume, stir briefly. Solution can be used immediately. Replace diluted solution every working day.

ORDER INFORMATION

Oasis Compac™ Neutral		
Disinfectant	10 litre container	3503983
Dosing unit	Manual pump adjustable dosing	3504008
Dosing pump	Manual pump (preset at 25mls)	3504009
Wall Bracket	Wall bracket to suit 10ltr drum	3504010



Dosing pump
Sink or bucket fill

CORPORATE HEADQUARTERS

Draegerwerk AG & Co. KGaA
Moislinger Allee 53–55 23558
Lübeck, Germany

www.draeger.com

DISTRIBUTION

Draeger Safety Pacific Pty Ltd
8 Acacia Place
Notting Hill VIC 3168
Australia

Phone 1800 372 437
Fax 1800 010 327

customer.service@draeger.com

DISTRIBUTION

Draeger Safety Pacific Pty Ltd
Unit 4, 24 Bishop Dunn Place
East Tamaki
Auckland 2013
New Zealand

Tel: 0800 372 437
Phone 1800 010 327